

# ACCESORIOS STANDARD PARA CONDUCTO CIRCULAR HELICOIDAL

STANDARD ACCESSORIES FOR HELICOIDAL CIRCULAR DUCTS / ACCESSOIRES STANDARD POUR CONDUIT CIRCULAIRE HÉLICOÏDAL




## CODOS AISLADOS

- Para salida de aire de campana, ventilador o caja de ventilación.

## INSULATED SLEEVES

- For air exit from hoods, ventilators or ventilation boxes.



## COUDES ISOLÉS

- Pour sortie d'air de hotte, ventilateur ou caisson de ventilation.

45°

### GALVA.-GALVA.

|              |           |
|--------------|-----------|
| CO C45 GG 12 | Ø 125-175 |
| CO C45 GG 15 | Ø 150-200 |
| CO C45 GG 20 | Ø 200-250 |
| CO C45 GG 25 | Ø 250-300 |
| CO C45 GG 30 | Ø 300-350 |

### INOX.-INOX.

|              |           |
|--------------|-----------|
| CO C45 II 10 | Ø 100-150 |
| CO C45 II 15 | Ø 150-200 |
| CO C45 II 20 | Ø 200-250 |
| CO C45 II 25 | Ø 250-300 |
| CO C45 II 30 | Ø 300-350 |
| CO C45 II 35 | Ø 350-400 |
| CO C45 II 40 | Ø 400-450 |

### INOX.-GALVA.

|              |           |
|--------------|-----------|
| CO C45 IG 10 | Ø 100-150 |
| CO C45 IG 15 | Ø 150-200 |
| CO C45 IG 20 | Ø 200-250 |
| CO C45 IG 25 | Ø 250-300 |
| CO C45 IG 30 | Ø 300-350 |
| CO C45 IG 35 | Ø 350-400 |
| CO C45 IG 40 | Ø 400-450 |

90°

### GALVA.-GALVA.


|              |           |
|--------------|-----------|
| CO C90 GG 12 | Ø 125-175 |
| CO C90 GG 15 | Ø 150-200 |
| CO C90 GG 20 | Ø 200-250 |
| CO C90 GG 25 | Ø 250-300 |
| CO C90 GG 30 | Ø 300-350 |

### INOX.-INOX.

|              |           |
|--------------|-----------|
| CO C90 II 10 | Ø 100-150 |
| CO C90 II 15 | Ø 150-200 |
| CO C90 II 20 | Ø 200-250 |
| CO C90 II 25 | Ø 250-300 |
| CO C90 II 30 | Ø 300-350 |
| CO C90 II 35 | Ø 350-400 |
| CO C90 II 40 | Ø 400-450 |

### INOX.-GALVA.

|              |           |
|--------------|-----------|
| CO C90 IG 10 | Ø 100-150 |
| CO C90 IG 15 | Ø 150-200 |
| CO C90 IG 20 | Ø 200-250 |
| CO C90 IG 25 | Ø 250-300 |
| CO C90 IG 30 | Ø 300-350 |
| CO C90 IG 35 | Ø 350-400 |
| CO C90 IG 40 | Ø 400-450 |



## ADAPTADOR

- Para salida de aire de campana, ventilador o caja de ventilación.

## ADAPTER

- For air exit from hoods, ventilators or ventilation boxes.

## ADAPTATEUR

- Pour sortie d'air de hotte, ventilateur ou caisson de ventilation.

### GALVA.-GALVA.

|              |           |
|--------------|-----------|
| CO ADP GG 12 | Ø 125-175 |
| CO ADP GG 15 | Ø 150-200 |
| CO ADP GG 20 | Ø 200-250 |
| CO ADP GG 25 | Ø 250-300 |
| CO ADP GG 30 | Ø 300-350 |

### INOX.-INOX.

|              |           |
|--------------|-----------|
| CO ADP II 10 | Ø 100-150 |
| CO ADP II 15 | Ø 150-200 |
| CO ADP II 20 | Ø 200-250 |
| CO ADP II 25 | Ø 250-300 |
| CO ADP II 30 | Ø 300-350 |
| CO ADP II 35 | Ø 350-400 |
| CO ADP II 40 | Ø 400-450 |

### INOX.-GALVA.

|              |           |
|--------------|-----------|
| CO ADP IG 10 | Ø 100-150 |
| CO ADP IG 15 | Ø 150-200 |
| CO ADP IG 20 | Ø 200-250 |
| CO ADP IG 25 | Ø 250-300 |
| CO ADP IG 30 | Ø 300-350 |
| CO ADP IG 35 | Ø 350-400 |
| CO ADP IG 40 | Ø 400-450 |