


SH01204 SH01208 SH01215



	SH01204	SH01208	SH01215
	JR.SH012A*	JR.SH012A*	JR.SH01215*
1	30A0017	30A0017	30A0017
2	52N0093	52N0094	52N0090
3	51C0081	51C0082	51C0078
4	53O0054	53O0055	53O0051
5	55M0023	55M0023	55M0020
6	15O0059	15O0059	15O0059
7	AZ3140	AZ3140	AZ3140
*8	58F0154	58F0154	58F0154
*9	12B0182	12B0182	12B0182
*10	57A0286	57A0286	57A0286
*11	---	---	58F0088
*12	12B0101	12B0101	12B0101
*13	57A0062	57A0062	57A0062
*14	12A0232	12A0232	12A0232
*15	57A0287	57A0287	57A0287
*16	12H0070	12H0070	12H0070
17	AZ0531	AZ0531	AZ0531
18	13D0094	13D0095	13D0062
19	12L0007	12L0007	12L0007

ATENCIÓN: Desmontar este cilindro sin el material adecuado es peligroso debido a la fuerza del muelle

CAUTION: Trying to disassemble this cylinder without proper material is dangerous because of the strong spring.

ATTENTION: Essayer de démonter le vérin sans le matériel adéquat devient dangereux a cause de la force du ressort.

